## LETTER

### Continuous-wave room-temperature diamond maser

Jonathan D. Breeze<sup>1,2</sup>, Enrico Salvadori<sup>3,4,5</sup>, Juna Sathian<sup>1</sup>, Neil McN. Alford<sup>1,2</sup> & Christopher W. M. Kay<sup>3,4,6</sup>

*Nature* volume555, pages493–496 (22 March 2018)

2018-04-30 Journal Club

## Contents

- Author
- Introduction
- Background
- Experiment Set-up
- Result

## Author

- Prof. Neil Alford
- Professor @ ICL

### LETTER

doi:10.1038/nature11339

### Room-temperature solid-state maser

Mark Oxborrow1, Jonathan D. Breeze2 & Neil M. Alford2



### ARTICLE

Received 6 Oct 2014 | Accepted 6 Jan 2015 | Published 20 Feb 2015

Enhanced magnetic Purcell effect in room-temperature masers

Jonathan Breeze<sup>1</sup>, Ke-Jie Tan<sup>1</sup>, Benjamin Richards<sup>1</sup>, Juna Sathian<sup>1</sup>, Mark Oxborrow<sup>1</sup> & Neil McN Alford<sup>1</sup>



**OPEN** Nanosecond time-resolved characterization of a pentacenebased room-temperature MASER

Received: 09 September 2016 Accepted: 29 December 2016 Published: 07 February 2017



npj Quantum Information

www.nature.com/npigi

Room-temperature cavity quantum electrodynamics with strongly coupled Dicke states

Jonathan D. Breeze 601,2, Enrico Salvadori 603,4,5, Juna Sathian 601, Neil McN. Alford 601,2 and Christopher W. M. Kay 603,4

doi:10.1038/nature25970

Continuous-wave room-temperature diamond maser

Jonathan D. Breeze<sup>1,2</sup>, Enrico Salvadori<sup>3,4,5</sup>, Juna Sathian<sup>1</sup>, Neil McN. Alford<sup>1,2</sup> & Christopher W. M. Kay<sup>3,4,6</sup>


Enrico Salvadori<sup>1,2,3</sup>, Jonathan D. Breeze<sup>4</sup>, Ke-Jie Tan<sup>4</sup>, Juna Sathian<sup>4</sup>, Benjamin Richards<sup>4</sup>, Mei Wai Fung<sup>2</sup>, Gary Wolfowicz<sup>1</sup>, Mark Oxborrow<sup>4</sup>, Neil McN. Alford & Christopher W. M. Kay 1,2

## Recent Research

- Continuous-wave room-temperature diamond maser, Nature(2018)
- Room-temperature cavity quantum electrodynamics with strongly coupled Dicke states, NPJ Quantum Information(2017)
- Nanosecond time-resolved characterization of a pentacenebased room-temperature maser, Scientific Reports (2017)
- Enhanced magnetic Purcell effect in room-temperature masers, Nature communications(2015)
- Room-temperature solid-state maser, Nature(2012)


# The first room-temp Maser

- Using p-terphenyl triplet state
- Long spin-lattice relaxation time (~135µs)



# The first room-temp Maser


## LETTER



*Nature* volume488, pages353–356 (16 August 2012)


## NV<sup>-</sup> center


- Long spin polarization time (~5ms)
- Long spin dephasing time (>1µs)
- Good thermal conductivity (1000 W/m·K)
- Good stability
- Easy to achieve the population inversion




## Population inversion

~80% of electrons in |0⟩









Physics Reports, 528 (2013), 1-45


N. Comm 6, 8251 (2015)


# **Experimental Validity**

- Q = 30000
- $N = 4.0 \times 10^{13}$
- $g_s = 0.7 \text{MHz}$
- $\kappa_c = \omega_c/Q = 1.9 \text{MHz}$
- $\kappa_s = 2/T_2^* = 3.9 \text{MHz}$
- $C = 4g_s^2 N/\kappa_c \kappa_s = 10.6 \gg 1$ 
  - → 180mW threshold











# Experimental Setup




# Experimental Setup



# EPR spectroscopy

- A=0.075mT
- -25MHz shifted (35°C increased)



## Maser emission

